Laptop Battery

How to replace your Laptop Battery?

1: Turn off your laptop and disconnect the AC adapter.
2: Release the latch or other attachment devices that hold your battery in place.
3: Slide the old battery out of its compartment or storage bay
4: Take the replacement battery for laptop out of the box.
5: Slide it into the notch or bay.
6: Close the safety latch to lock it into place.
7: Reconnect the AC adapter and give the new battery for your notebook a full charge.

Unique solution ID: #1038
Author: Secure-Battery.com
Last update: 2022-11-29 12:44

(c) 2026 Secure-Battery.com <webmaster@secure-battery.com> | 2026-09-10 19:00
URL: https://faq.secure-battery.com/content/1/39/en/how-to-replace-your-laptop-battery.html